



INSTALLATION

KIT - QUARTER WHEEL OPENING COVER

B9A-6527964-A
(STAINLESS)

B9A-6527964-B
(PRIMED)

Before color painting Panel Assembly, three $\frac{7}{32}$ " dia. holes must be drilled in Fender Flange for attaching Guide Pins. (See View C).

First place Panel Assembly into position in opening of Fender having Hook End of Lock Lever over Fender Flange and push up Lock Rod into locked position. With Panel Assembly flush with face of Fender, locate center of front holes centrally with slot in Panel Assembly. (See view A). Center of rear hole should be located $\frac{1}{8}$ " rearward of center of slot in Panel Assembly. (See view in circle C).

Remove Panel Assembly, drill holes, attach Guide Pins and color paint Panel Assembly

To install Panel Assembly, front Guide Pins should enter front slots first, swing Panel Assembly all the way up into Fender opening which will then engage rear Guide Pin and lock into place with Lock lever. (See section B-B).